MODEL: 324590RB
PACKING DIAGRAM




ARM
SOCKET
METAL FRAME
CORD
SWITCH
SHELL DROPS
(23 PCS)
SHELL DROPS
(18 PCS)
UPPER POLE
SOCKET RING
SHELL DROPS
(12 PCS)
MIDDLE POLE
LOWER POLE
BASE
POWER
CORD
SCREW

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS LAMP SHOULD TAKE APPROXIMATELY 20 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: METAL FRAME, (53) SHELL DROPS, SOCKET RING, ARM ASSEMBLY, UPPER POLE, MIDDLE POLE, LOWER POLE, BASE AND SCREW. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

ASSEMBLE THE LAMP

1. CAREFULLY ORGANIZE AND PLACE ALL PARTS ON A SMOOTH, FLAT SURFACE. LINE UP ALL OF THE PARTS ACCORDING TO THE ASSEMBLY DIAGRAM.

2. TUCK AND INSERT THE EXCESS CORD INTO THE HOLE OF ARM.

3. SCREW THE ARM ONTO TOP OF THE UPPER POLE.

4. SCREW THE MIDDLE POLE TO BOTTOM OF THE UPPER POLE.

5. SCREW THE LOWER POLE TO BOTTOM OF THE MIDDLE POLE.

6. SECURE THE POLE ASSEMBLY TO TOP OF THE BASE WITH A SCREW.

7. ATTACH (53) SHELL DROPS TO THE METAL FRAME AS SHOWN.

6. PLACE THE METAL FRAME WITH SHELL DROPS OVER THE SOCKET AND SECURE WITH THE SOCKET RING.

7. INSTALL A 150 WATT MAXIMUM MEDIUM BASE TYPE "A" BULB (NOT INCLUDED) INTO SOCKET.

8. PLUG THE POWER CORD INTO AN OUTLET AND TURN ON AT SWITCH.

BULB REPLACEMENT

1. BEFORE REPLACING THE BULB, BE SURE THAT THE SHADE AND BULB ARE COOL AND LAMP IS UNPLUGGED.

2. UNSCREW EXISTING BULB FROM SOCKET AND REPLACE WITH A NEW BULB. PLUG POWER SUPPLY CORD BACK INTO OUTLET.

TROUBLE SHOOTING

1. IF YOUR LAMP DOES NOT LIGHT, CHECK PLUG AT THE OUTLET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE POWER OUTLET.

2. IF LAMP STILL DOES NOT LIGHT, UNPLUG FROM OUTLET. CHECK THE BULB FOR A BROKEN FILAMENT. REPLACE BULB IF NECESSARY, PLUG IN LAMP AND TURN IT ON.

3. IF THE LAMP STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.